



Field-IQ

ISOBUS WEATHER STATION

The Trimble® Field-IQ™ ISOBUS weather station informs you of instantaneous changes in the weather and is available via the easy-to-use ISO Universal Terminal (UT) interface. Wind speed and direction are measured using four ultrasonic transducers. No moving parts results in better durability and reliability.

The internal GPS engine and three-axis solid-state compass make it possible to provide both apparent and true wind speed and direction without the need to add additional sensors. The internal temperature and barometric pressure sensors help predict changing weather patterns.

The Weather Station also displays the Delta T value, which is one of the standard indicators for determining acceptable spray conditions. It is calculated by subtracting the wet bulb temperature from the dry bulb temperature. Delta T indicates the droplet lifetime in relation to the evaporation rate.

REAL TIME

Monitor weather values in real time on the Trimble GFX-750™ display system and TMX-2050™ display to see how the liquid chemicals you spray will be affected.

RECORD KEEPING

Weather information can be logged by a compatible ISO terminal so you can pull at a later date for review and documentation.

SENSOR

Detect different weather data and display it on an ISOBUS terminal. The ISOBUS-Task Controller (TC) application will save the measured weather data.

AT A GLANCE READ-OUT

View values such as speed and direction of true wind, speed and direction of apparent wind, gust speed, temperature, relative air humidity and air pressure, dew-point, drift, Fire Index readout and alarm on the weather station's configurable Run Screen.

Advantages

- ▶ Works on all ISOBUS displays – Weather conditions are documented via ISOBUS Task-Controller
- ▶ Provides field-specific weather information in the cab
- ▶ Supports on-the-go application decisions
- ▶ Configurable alarms for certain conditions



Contact your local Ag reseller today

NORTH AMERICA
 Trimble Inc.
 10368 Westmoor Drive
 Westminster, CO 80021
 USA
 +1-720-887-6100 Phone
 +1-720-887-6101 Fax

Trimble Inc.
 Corporate Headquarters
 935 Stewart Drive
 Sunnyvale, CA 94085
 USA
 +1-408-481-8000 Phone
 +1-408-481-7740 Fax

EUROPE
 Am Prime Parc 11
 65479 Raunheim
 GERMANY
 +49-6142-2100-0 Phone
 +49-6142-2100-140 Fax